


PRACTICE MODE


IMPORTANT: Practice mode screw must be removed before hunting. Broadhead blades will not deploy unless practice screw is removed.



Install practice mode screw.




Ready for practice. *Only shoot into broadhead approved foam targets. Do not shoot into bag targets.*




To return to hunting mode, remove practice mode screw, inspect the blades for damage, and remove any target debris.

CLOSING BLADES




Pivot a blade into ferrule.




Insert wedge tool between blade and deployment arm (as shown). Return exposed blade into ferrule.


REPLACING BLADES




Remove and discard used pivot screw, blades, and wave washer.



Overlap **NEW left blade over right blade** in the opened and locked position. Slide blades into ferrule slot.



Rotate **NEW** blades into the closed position. Install wave washer into ferrule as shown. Washer must be positioned between ferrule and blade. Make sure the convex side of the washer touches the blade.



Install **NEW** screw into pivot hole.

**Tip: Hex wrench can be inserted into pivot-screw hole to center all parts.*

sevrbroadheads.com

SEVR™

STRAIGHT THROUGH IT.




sevrbreadheads.com

⚠ WARNING: HANDLE WITH EXTREME CAUTION! This product is designed to inflict catastrophic hemorrhaging and a fast, efficient death to legal game animals. Failure to handle properly will cause serious injury or death. To avoid injury, read all enclosed instructions prior to use or SEE WARNINGS AND USE @ www.bsaf.ws or 877-463-6387.

⚠ WARNING: Cancer and Reproductive Harm—www.P65Warnings.ca.gov

PARTS



To reorder breadheads and parts scan code or visit: sevrbreadheads.com



PN 728152 revC